SmartBlock™ Inside & Semi-Inside Fit Installation Guide

Tools Required

- Cordless drill & drill bits
- Phillips screwdriver

Installation Steps

1. **Install the Cassette Box**
   Do not crease or remove the light-block film on both sides. Ensure jamb depth is at least 20mm. Fix cassette using the 32mm screws provided
2. **Insert Blind into Cassette**
   Install control end into the cassette bracket. Press the end plug button and slide into the bracket hole. Lock with bracket pin
3. **Install Side Channels**
   Press lock point and slide safety tensioner to bottom (Chain control option only). Remove paper band and test blind. Clip side channels into cassette end caps. Use U-shaped PVC card to expose screw holes and screw into jamb. Insert bottom channel and secure with screws
4. **Attach Cassette Cover**
   Hook the top edge of the cover onto the cassette, then swing down to lock. For Chain control blinds: ensure the control chain isn't pinched
5. **Secure Safety Tension Device** (chain control blind option only)
   Attach holder to pre-drilled hole with 'TOP' facing up. Press lock point, snap device into place, and ensure chain is taut

Tip: For chain-free or motorised SmartBlock™ blinds, simply skip the chain/tension steps included above

Need a visual guide?

Watch the full SmartBlock™ Inside Fit installation video here:
https://www.blindsonline.net.nz/faq/smartblock/how-do-i-install-smartblock-blackout-blinds-as-an-inside-fit

blindsonline