

Aluminium Blind Installation (Inside Fit)

1

Fitting the brackets

Fit the brackets at your chosen depth inside the window jamb

It's generally best to position brackets slightly back from the architrave face, rather than hard against the rear of the jamb.

Around 10 mm back from the architrave face usually gives a clean appearance while ensuring the blind clears any window handles or protrusions when raised and lowered

Bracket quantity guide

Bracket quantity depends on blind width:

- Up to 1 m wide - use 2 brackets
- 1-2 m wide - use 3 brackets
- 2-3 m wide - use 4 brackets
- 3-4 m wide - use 5 brackets

Measure approximately 105 mm in from each end of the window and fix the two end brackets first. If additional brackets are required, space them evenly across the width

Important

A bracket must never be fixed directly above the control unit or a ladder cradle. Each bracket must sit between the control unit and the first ladder cradle on either side

Tip: Laying the blind on the windowsill allows you to clearly see where the control unit and ladder cradles sit within the headrail, helping you position brackets accurately before drilling

2

Fitting the blind

Once all brackets are securely fixed, clip the aluminium Venetian blind into place

Ensure

- Each bracket clicks firmly into the headrail
- The control wand and pull cord sit at the front of the headrail, facing into the room

After fitting, gently raise, lower, and tilt the blind to confirm smooth operation. If anything feels tight or uneven, unclip the blind and check bracket alignment before proceeding. Once satisfied, your aluminium Venetian blind is ready for everyday use